



PRO USER MANUAL

www.etbinstruments.com

Contents

1	DigiDash² Introduction.....	4
1.1	Datalogger Key Features.....	4
1.1.1	Datalogger Front View	5
1.1.2	Datalogger Rear View.....	6
1.2	Display Key Features	6
1.2.2	Display Front View	7
1.2.3	Rear View.....	8
1.3	Packaging Checklist.....	8
2	DigiDash Installation	9
2.1	Mounting the Datalogger.....	9
2.2	Mounting the DigiDash ² Display.....	9
2.3	Sensor Installation	10
2.3.1	Speed sensor (<i>POWER/TRIGGER Cable</i>)	10
2.3.2	Oil & Water Temperature Sensors.....	11
2.3.3	Oil & Auxiliary Pressure Sensors	11
2.3.4	Fuel Level Sensor.....	12
2.3.5	Lap Timer Receiver	12
2.4	Wiring the DigiDash ² Datalogger	13
2.5	Connecting the DigiDash ² Display	13
2.6	Ignition Systems / Tachometer Wiring	13
3	Configuring DigiDash²	15
3.1	Configuration via Display	15
3.1.1	Selecting SETUP MODE	15
3.1.2	Exit Setup Mode.....	15
3.1.3	Button Function (Setup Mode)	16
3.1.4	Setup Mode Menu Detail	17
3.2	Configuration Using DigiTools Software.....	22
4	Using the DigiDash² Display	23
4.1	Button Functions (General Operation)	23
4.2	RED 3-Digit LED Display	24
4.2.1	Speed.....	24
4.2.2	RPM.....	24
4.2.3	Engaged Gear	24
4.2.4	Warning Alarms	25
4.2.5	Logger Status	25
4.3	GREEN LCD Character Display	25
4.3.1	LCD Display Screens in Detail	26
4.4	Lap Timing	27
4.4.1	Manual Lap Timing / Track Day Mode.....	27
4.4.2	Infra-Red Lap Trigger / Race Day Mode	27
4.4.3	GPS Lap Timing.....	28
4.5	Acceleration Timer.....	30

4.5.1	Acceleration runs:	30
4.5.2	Braking runs:	30
4.6	Troubleshooting	31
5	DigiTools PC Software.....	32
5.1	Connecting the Serial Cable to a PC.....	32
5.2	Installing the DigiTools Software	32
5.3	DigiDash² Configure	33
5.3.1	Version Tab	33
5.3.2	General Tab	35
5.3.3	Alarms Tab	37
5.3.4	Display Tab	38
5.3.5	Shift Lights Tab.....	39
5.3.6	Lap Tab	40
5.3.7	Gear Tab.....	41
5.3.8	Fuel Tab	42
5.3.9	Calibrate Tab	42
5.3.10	Logger Tab.....	44
5.4	DigiDash² Analysis	45
5.4.1	Downloading Logged Data from the DigiDash ²	45
5.4.2	Download Menu Screen	46
5.4.3	Data Analysis.....	47
Appendix 1– Wiring Schematic.....		48
Connecting to an Existing Wiring Loom / Switches		48
Connecting to an Existing Wiring Loom / Switches		49
SENSOR Cable Inputs that require switched +12v		49
SENSOR Cable Inputs that require switch to Ground (-ve).....		49
Appendix 2 - Speed Sensor Installation.....		50
Speed Sensor Alignment.....		51
Appendix 3 – Display Mounting Template (to scale).....		52
Appendix 4 – ETB Fuel Sender Fitting Instructions.....		53
Fitting the sender to the fuel tank.....		53
Fuel Sender Adjustment.....		53
Appendix 5 – Lap Trigger Alignment.....		54
Appendix 6 – Specification.....		55
Power Supply		55
Environmental.....		55
Physical.....		55
Cleaning/Care		55
Warranty.....		55

1 DigiDash² Introduction

The DigiDash² is easy to use and install. Most people will get the hang of the unit in a few minutes. This manual is provided as guide and reference.

Before cutting any holes or wires, please read through this manual.

The DigiDash² consists of separate Datalogger and Display units. The Display allows you to configure the main parameters without the need for a PC. The Datalogger without a Display connected requires a PC to configure. The Datalogger is mounted on a flat surface inside the vehicle cockpit, whilst the Display unit can be mounted either directly on the Dashboard or on the steering wheel itself. In either mounting position, the A and B function buttons can be remotely wired using a remote button kit available from ETB Instruments. This kit comprises four buttons, two of which extend A and B, and two others that provide extra menu functions.

1.1 Datalogger Key Features


The Datalogger can be used as a stand-alone unit without a display connected, logging numerous vehicle parameters. This data can then be downloaded to a Laptop PC and analysed using the accompanying DigiTools Software.

The parameters which can be recorded are:

- Engine Revs (RPM);
- Speed (MPH or KMH);
- Engaged Gear;
- Oil Pressure;
- Oil Temperature;
- Water Temperature;
- Fuel Level;
- Auxiliary Pressure (Can be used for Fuel or Boost Pressure);
- Battery Voltage;
- Brake %
- Longitudinal G-Force;
- Lateral G-Force
- Odometer (metres)
- Lap Number
- Lap Times (s)
- Split Times (s)
- PRO+ Extra 0-5v Channels 1-4



Note: References to the Datalogger relate to the Datalogger box. The word 'Logger' is used to describe the recording of data.

1.1.1 Datalogger Front View



1.1.1.1 POWER Indicator





The **Green** LED illuminates when the unit is switched on, powered up and operational.

- | | | |
|---|-------------------|--|
|  | Light On: | Power Supply OK. Functioning Normally |
|  | Light Off: | No Power Supply. |

1.1.1.2 STATUS Indicator

The **Red** LED has two modes of operation, which can be programmed via the DigiTools:

- **Sensor STATUS** – (Default Setting) The LED functions as an individual signal test LED for the speed sensor, tachometer (RPM) and lap trigger sensor. The LED will illuminate when one of these 3 signals is triggered. For example, this can be used to check whether the speed sensor is detecting a magnet as it passes the sensor head. Once all the sensors are checked the Status Light can be configured to show:
- **Logger STATUS** – The LED will indicate the Status of the Logger.

	Light Off:	Logger is switched off.
	Light On:	Logger is on. (Recording Data)
	Light Flashing Slowly:	Logger Memory Full
	Light Flashing Rapidly:	Memory Error. (Contact ETB)


1.1.1.3 SERIAL Port

Using the serial link cable supplied with the DigiDash2, the Datalogger can be connected to a laptop computer via this port in order to download / delete logged data or configure the DigiDash2 functions. A USB / Serial converter is included for connection to Laptops with only USB ports available.

1.1.1.4 DIGICAN Port

This connection is the CAN bus link to the Display unit via the cable supplied. This cable has red connector housings on each end and should not be confused with the Serial port extension cable.

1.1.2 Datalogger Rear View



1. POWER/TRIGGER Port

Inputs to this connector include 12v supply, Ground, Speed, RPM and for a stand-alone ON/OFF switch for Logging data.

2. SENSORS Port

All major sensors and other logged inputs are connected to this port.

1.2 Display Key Features

The DigiDash² has multi-purpose displays to show a variety of vehicle parameters.


The displays include:

- Engine Revs (RPM);
 - Sequential gear shift-up lights;
 - Speed (MPH or KMH);
 - Gear;
 - 2 axis G-Sensor
 - Water Temperature in °C/°F
 - Oil Pressure in PSI/BAR
 - Auxiliary Pressure (Can be used for Fuel or Boost Pressure)
 - Oil Temperature in °C;°F
 - Fuel Level;
 - Battery Voltage;
 - Power (BHP)
 - Last & Best Lap Times;
 - Acceleration/Deceleration Time;
 - Trip Time, Distance and Average Speed Display;
 - Engine Hours
 - Max Holds on all Key Parameters;
 - Odometer;
 - Alarms for 2 Pressures, Oil Temperature, Water Temperature and Fuel Level.
 - Turbo Boost*
 - Brake Pressure / Bias Front & Rear*
 - Air / Fuel Ratio (Lambda)*
- * Using 0-5v Channel inputs

The DigiDash also integrates 6 Warning Lights, of which the Auxiliary (AUX) warning light can be configured using the software to display one of 3 different functions:-


- Main Beam;
- Fog Lights;
- Direction Indicator;
- Ignition/Low Battery;
- Brake Fail / Handbrake on Warning;
- Auxiliary
 - Over Speed Warning
 - Logger On / Off
 - Neutral Gear (for bike-engined vehicles)

1.2.2 Display Front View



1. Sequential gear shift up lights – can be used in two different modes
2. Dashboard warning lamps
3. Large 3 digit 7 segment (Red) LED display for Speed, Gear, RPM or Warning Alarms. Decimal point on the 1st Digit can be programmed to indicate that the DataLogger is recording.
4. Simple 2 button controls, marked **A** & **B**.
5. Large backlit (Green) LCD display for sensor readouts, menus and warnings.

1.2.3 Rear View



1. **DIGICAN** Connector – This should be connected to the **DIGICAN** port on the Datalogger.
2. External Button Connector & GPS Connection – This can be used for connecting 4 external buttons – 2 duplicate buttons for A & B and 2 others, C and D, for accessing extra functions. A further 9 way connector connector on a flying lead is used for connecting to the GPS receiver.

1.3 Packaging Checklist

Standard Items:


	Qty
Datalogger	1
Display	1
Water Temperature Sender	1
Oil Temperature Sender	1
Oil Pressure Sensor	1
Fuel Level Sender	1
Magnets for prop shaft	2
Wiring Harnesses (Power/Sensor/CAN/Serial/Button/USB)	6
Lap Timer Receiver (Infra Red)	1
Speed Sensor	1
0-5v Channel Module	1
DigiTools CDRom + Serial / USB Driver CDRom	1
M3 Mounting Bolts	8
Quick Start Guide	1
DigiDash Stickers	2

2 DigiDash Installation

2.1 Mounting the Datalogger

The Datalogger incorporates a 2-axis G-Force sensor within the unit. Although these axes can be reversed using the DigiTools software to suit either longitudinal or lateral mounting positions within the vehicle's cockpit, it is essential that the Datalogger box is mounted on a flat surface for the G-sensor to zero correctly.

The recommended orientation of the Datalogger box as follows:-



2.2 Mounting the DigiDash² Display

Before cutting any holes in the dashboard, make sure that the location of the DigiDash² is easily visible from the driver's final position. Also ensure that there is sufficient clearance behind the unit for the connectors and loom.

Note : The DigiDash² Display should be directed towards the driver. If the dash is mounted at too steep an angle the shift lights and warning lights will not be easily visible.

The DigiDash² has been designed to mount either on a flat dash panel behind the steering wheel or by using a fixing bracket, the steering wheel itself.

Templates for the fixing screw holes on the Display unit are shown in Appendix 3.

2.3 Sensor Installation

2.3.1 Speed sensor (*POWER/TRIGGER Cable*)

The DigiDash² is supplied with a solid state speed sensor and this must be used to provide the speed signal for the DigiDash². The sensor consists of a hall-effect magnetic pickup housed in an M12x1.5mm Nylon threaded rod.

Two magnets are provided for attachment to either a propshaft, wheel hub or drive-shaft coupling. The magnets should be fixed in position using Epoxy Resin Adhesive, sometimes known under the trade name of 'Araldite'. If you have the choice it is recommended to install the speed sensor on the propshaft as accuracy will be improved.

The magnets have small 'dots' on one face. These denote the magnet's North pole. The magnet MUST be mounted with the dot facing down. For further help in setting up the speed sensor and magnets, please refer to Appendix 2 (Section 6).

You will need to fabricate a suitable metal bracket to hold the sensor in a position such that the magnets pass in front of the sensor as they rotate in relation to the vehicle's speed. Using the threaded body and nuts supplied, the sensor should be adjusted until the gap between the sensor and magnets is approximately **1mm**

The sensor must be mounted so that this gap remains constant. This means that the sensor must be mounted such that it moves in unison with the surface upon which the magnets are mounted. Examples of this would be:-

<u>Magnets location</u>	<u>Sensor Bracket Location</u>
Differential / Propshaft Flange	Differential Casing
Propshaft – Gearbox output	Gearbox
Front wheel hub	Steering arm

(Please see Quick Start Guide or Appendix 2, Section 6 for further visual reference.)

The **red STATUS** LED on the Datalogger can be used to verify that the Speed Sensor is receiving a signal as each magnet passes in front of it. In order to do this you must first set the operation of the **STATUS** LED on the Datalogger to Sensor Mode using the DigiTools Configure software (General Settings TAB).

Simply turn the propshaft (or component on which the magnets are mounted) by hand and you should see the **red STATUS** LED illuminate.

In addition, the Display TEST MODE can be used to test speed, rpm, and infra-red lap trigger inputs.

2.3.2 Oil & Water Temperature Sensors

Oil and water temperature senders are supplied as standard. To ensure accuracy in the display it is essential that these senders are used with the DigiDash. Use of other senders is not permitted and will result in inaccurate readings.

Note : The DigiDash is calibrated to provide accurate readings over the range 40°C to 140°C only. If the sensor is not connected properly, then the display will show NC (Not Calibrated or No Connection).

Most engines have the water temperature sender located either in the radiator, or in the cylinder head. To maintain accuracy please use this sensor in the standard location for your engine. If the existing water temperature sensor is required by the engine management system, an alternative location will need to be found.

Oil / Water Temperature Sender 1/8" NPTF Thread	ETB Part# 470010
--	------------------

Thread adapters are available separately from ETB to suit the many engine variants.

The body of the sensor must be earthed for the sensor to function correctly. If the sensor is not connected properly the DigiDash will display 'NC' or may not produce accurate readings. Sensor earthing can be achieved either through the component into which the sensor screws, or by clamping a spade connector to the sensor body with a jubilee clip. If the reading on the DigiDash2 changes when a wire is temporarily connected from the sensor body to earth, you should earth the body separately as the sensor mounting itself is not providing a good earth.

2.3.3 Oil & Auxiliary Pressure Sensors

A pressure sensor is included with the DigiDash2 as standard and measures pressure to a maximum of 145 PSI / 10 BAR, usually for oil used for engine oil pressure. The DigiDash2 is designed to work correctly with this sensor only. To ensure accuracy in the display it is essential that this sender is used with the DigiDash. Use of other senders is not permitted and will result in inaccurate readings.

Note : For motorcycle engined cars, it is essential to remote mount the oil pressure sensor rather than directly onto the engine block. This is to prevent premature failure of the sensor caused by the high frequency vibration generated by high-revving motorcycle engines. A remote mount kit is available separately from ETB – please telephone +44 (0)1702 601055 for details.

!! Important - ETB Instruments will not replace faulty oil pressure sensors under warranty unless it can be proved that the sensor was correctly remote-mounted!!

The body of the sensor must be earthed for the sensor to function correctly. If the sensor is not connected properly the DigiDash will display 'NC' or may not produce accurate readings. Sensor earthing can be achieved either through the component into which the sensor screws, or by clamping a spade connector to the sensor body with a jubilee clip. If the reading on the DigiDash2 changes when a wire is temporarily connected from the sensor body to earth, you should earth the body separately as the sensor mounting itself is not providing a good earth.

A second pressure sensor can be purchased separately and connected to the Datalogger to measure an additional source. As examples, this could be used for fuel pressure or positive boost pressure .

Auxiliary Pressure Sender (with low pressure switch built in) 1/8" NPTF Thread	ETB Part# 38007025053
--	-----------------------

2.3.4 Fuel Level Sensor

The DigiDash2 is supplied with ETB's standard 6-hole, top-mount lever-arm fuel sender, and the default setting in the DigiTools configuration is set for this sensor.

However, alternative sensors, available separately from ETB, can be used by configuring the Digidash2 using the DigiTools software. These are:-

VDO Lever-Arm Fuel Sender
VDO Dip-Pipe Fuel Sender
Capacitive Type tube sensor (resistance range 10-180Ω)
Stewart Warner Type (240-33Ω)

To ensure accuracy in the display it is essential that one of these sensors is used with the DigiDash2. Use of other senders is not permitted and will result in inaccurate readings.

If the sensor is not connected properly the DigiDash will display 'NC'.

Additional Fuel level sender fitting instructions for the standard ETB lever-arm sensor can be found in Appendix 9.

2.3.5 Lap Timer Receiver

The Lap timer module uses an infra-red sensor similar to that used in television sets. This is designed to be used with any common track beacon, or the optional infra-red beacon from ETB.

The lap timer receiver module is housed in a small plastic box, which has a cut-out with the sensor clearly visible. This sensor should be firmly fixed to the side of the vehicle that is exposed to the trackside beacon (note that the side required may vary at different circuits, so you may wish to mount the receiver so as to allow it to face either side, e.g. with tie wraps.

The range of the sensor is around 20 metres so should be sufficient for most tracks.

Problems with the lap timer can be diagnosed using either the Datalogger **red STATUS** LED in Sensor Mode or the Display Test Mode and your TV remote control.

For further details on using the DigiDash² Lap timing system please refer to section 3.4.

For details on wiring please see the wiring section at the end of the document.
Please see the drawing in Appendix 5 for mounting details.

2.4 Wiring the DigiDash² Datalogger

All main connections to the DigiDash² are made via two 15-way D-type connectors on the Datalogger, marked **POWER/TRIGGER** and **SENSORS**.

These two connectors are colour-coded to match the coloured stripes on the Datalogger, and are gender specific to prevent incorrect connection.

The blue colour connector should be plugged in to the **SENSOR** connector on the Datalogger box. The **SENSOR** cable has 12 wires all of 1 metre length. These wires are intended to be joined into the existing wiring of the vehicle. The joints can be made in several ways, including ScotchLocks and soldering. Simply twisting the wires and covering with tape is NOT a good method of wiring the DigiDash and will result in unreliable joints. A well-soldered and insulated joint or crimp connectors are the best means of wiring the vehicle.

The **POWER/TRIGGER** cable with the green connector is supplied with a suitable length of cable for the lap trigger to suit most vehicles and does not require connection to the existing wiring loom. The cable includes the speedometer sensor, lap trigger input, the RPM input, main power 12v feed + ground wire and an optional wire for a single pole / single throw toggle switch (used for switching the data recording facility (logger) on or off). This cable also incorporates a connection to the 0-5v module for connecting an additional 4 channels.

2.5 Connecting the DigiDash² Display

The Datalogger is connected to the main Display unit via a CAN bus link cable. This is identified by the red 9-way D-type connectors, and is the same gender at each end. This means that it does not matter which way round you connect the cable.

One end of the cable is connected the Datalogger port marked with a red stripe and the word **DIGICAN**. The other end is connected to the 9-way socket on the Display unit. The Display connectors are gender specific and cannot be incorrectly connected.

Please refer to Appendix 1 for the full details of the wiring.

2.6 Ignition Systems / Tachometer Wiring

The green **POWER/TRIGGER** connector incorporates the tachometer input lead (see wiring diagram).

The DigiDash² RPM monitor is designed to connect directly into a variety of different ignition systems. There are a huge variety of systems used in vehicles. The feed for the RPM tachometer wire (red wire) should come from a Low Voltage Connection (e.g. the negative (-ve) side of the ignition coil). On many vehicles this will most likely be from the IGNITION COILS LT connection. On engines that feature modern ECU's (also called CDI's with bike engines) there may be a dedicated TACHO output. This is usually routed to the car's rev-counter and is the ideal position to which to connect the tachometer wire.

WARNING

Under no circumstances should the tacho feed be taken from a High-Tension circuit (from the HT side of a coil, or a spark-plug). This will DAMAGE the unit and will invalidate the product's guarantee.

The **red STATUS** LED on the Datalogger can be used to verify that the tachometer input is receiving a good signal. In order to do this you must first set the operation of the **STATUS** LED on the Datalogger to Sensor Mode using the DigiTools Configure software (General Settings TAB).

The **red STATUS** LED will illuminate on receiving a pulsed signal on the tachometer input.

Note : Some ECU's may require a pull-up resistor to 'pull-up' the output signal voltage to 12v. Please contact ETB Instruments should you experience problems with a tachometer input.

3 Configuring DigiDash²

The setup and various parameters of DigiDash² can be configured either directly using the Display or via a Laptop using the DigiTools software.

3.1 Configuration via Display

3.1.1 Selecting SETUP MODE

This mode allows the user to define all essential parameters when setting up the DigiDash² to match the vehicle's specifications. It also allows the user to turn on or off certain functions, or to set the required DigiDash² display brightness / contrast levels.

(NOTE- If you have a Windows based personal computer, you can use the software supplied to directly change all the parameters that can be normally accessed via SETUP MODE as well as a host of extra features. To do this, please refer to the section headed "DigiTools PC Software" under Section 5.)

To enter **SETUP MODE**:


- Ensure DigiDash2 is turned ON;
- Hold down the LEFT (A) and RIGHT (B) dash buttons for 2 seconds.



To enter the set-up Menu, Hold Down Buttons A & B together for 2 seconds

You should see the LCD show TEST MODE, which is the first menu screen. To move to the next Menu screen, press Button 'A'. To Edit the Menu displayed, press Button 'B'. Once you have finished editing a particular Menu screen, press Button 'A' (shown on LCD as 'Ok') to return the Main editing menu. For a full explanation of the button functions in Setup mode, please refer to Section 3.1.3 on the following page.

3.1.2 Exit Setup Mode



To **QUIT** SETUP mode, press buttons A & B together for 2 seconds and you will be asked if you wish to exit SETUP mode. Press button A ('YES') to exit.

3.1.3 Button Function (Setup Mode)

The DigiDash² buttons have different functions depending on whether you are in Setup (Configuration) Mode, or using the buttons during general operation (See Section 3.1).

Even more functionality is accessible when using the remote button kit (contact ETB for details) which is attached to the connector on the back of the display unit. This allows you to remote mount buttons on a steering wheel for instance. The remote button kit has 4 buttons. Two duplicate Buttons **A** and **B**, and two others, **C** and **D**.

Button A	Press Once	Moves to the Next LCD display screen
	Hold Down	No Function
Button B	Press Once	Press to Edit and increase (Add) numeric parameter
	Hold Down	When changing numeric parameter, number increases at a faster rate

If a remote button kit is connected, the following functions are available using Buttons **C** and **D**.

Button C	Press Once	Moves to the Previous LCD display screen
	Hold Down	No Function
Button D	Press Once	Decreases numeric value
	Hold Down	When changing numeric parameter, number decreases at a faster rate

3.1.4 Setup Mode Menu Detail

After selecting SETUP MODE you will see the first of the menu options on the main LCD display that the can be adjusted (**Brightness**). You can either continue to the **NEXT** menu by pressing button A, or **EDIT** the displayed menu by pressing button B.

There are 38 Setup menu options as shown below. Each option is described in more detail below (Note that setup screens for Gears 2-6 are not shown below).

Test Mode Next->Quit<-Edit	➤	GPS Mode Next->Quit<-Edit	➤	Brightness Next->Quit<-Edit
Contrast Next->Quit<-Edit	➤	Lap Blank Next->Quit<-Edit	➤	LED Startup Menu Next->Quit<-Edit
Reset/Clear Next->Quit<-Edit	➤	MPH or KMH Next->Quit<-Edit	➤	Water Temp Alarm Next->Quit<-Edit
Oil Temp Alarm Next->Quit<-Edit	➤	Oil PSI Alarm Next->Quit<-Edit	➤	RPM/PSI Alarm Next->Quit<-Edit
Aux PSI ALARM Next->Quit<-Edit	➤	Fuel Level Alarm Next->Quit<-Edit	➤	Shift Mode Next->Quit<-Edit
Shift RPM Next->Quit<-Edit	➤	Shift Delta Next->Quit<-Edit	➤	RPM Uplift % Next->Quit<-Edit
Pulses/Cycle Next->Quit<-Edit	➤	Speedo Cal Next->Quit<-Edit	➤	Gear Cal Next->Quit<-Edit
Track Length Next->Quit<-Edit	➤	Accel Test Start Next->Quit<-Edit	➤	Accel Test Stop Next->Quit<-Edit
Ueh Weight Kg Next->Quit<-Edit	➤	Primary Ratio Next->Quit<-Edit	➤	Num Gears Next->Quit<-Edit
Gear 1 Next->Quit<-Edit	➤	Clock Day Next->Quit<-Edit	➤	Clock Month Next->Quit<-Edit
Clock Year Next->Quit<-Edit	➤	Clock Hour Next->Quit<-Edit	➤	Clock Minute Next->Quit<-Edit

If you choose to **EDIT** a menu option, two alternative choices can be made:

1. Accept the value displayed, and return to the Options Menu. This is done by pressing Button A, indicated as 'Ok'.
2. Change the value of your chosen parameter. This is done by pressing button B. To increase the value in larger increments, just hold down button B.



Button-A accepts the value and returns to the menu selections

Button-B increases the value. Hold down the button to increase the value in larger step sizes.

3.14.1 Test Mode

```

SP  RP  LT  SW
++  --  --  --

```

This mode can be used to check that the DigiDash is receiving a signal for the following inputs: Speed (SP); RPM (RP); Infra-Red Lap Timer Receiver (LT) and manual switch (SW).

For example: To check that the speed sensor is sensing magnets, rotate the shaft / wheel by hand so that magnets pass in front of the speed sensor – as the magnet is detected “++” should appear under the SP heading (as shown above).

3.14.2 GPS Mode

```

GPS Mode
Ok  GPS 5Hz  UP

```

If your DD2 is GPS enabled and you have purchased a GPS receiver from ETB, you will be able to edit this screen. The GPS mode enables the user to select from 1Hz or 5Hz GPS receivers.

3.14.3 Brightness

```

Brightness
Ok   6   Add

```

This value sets the display brightness for the large 7-segment red LED display, the shift lights and warning lights. The range is from 0 (very faint) to 15 (very bright). The default setting is 8.

3.14.4 Contrast

```

Contrast
Ok   6   Add

```

This value sets the contrast for the main LCD display. The range is from 0 (very dark) to 15 (very light). The default setting is 6.

3.14.5 Lap Blank

```

Lap Blank
Ok   48   Add

```

The Lap timer receiver supplied is designed to use any form of trackside infrared beacon. These are present at most tracks. For accurate results, it is important that you pick up a signal from only one beacon at a time.

To do this, the DigiDash2 must be set to reject other beacons. This is done by setting the “Lap Blank” period, which is the time (in seconds) that the DigiDash2 will wait before it starts to look for beacons again.

For example: If you are lapping in around 1min 30secs set the Lap Enable Time to 75 (1min 15secs). In other words, after DigiDash registers a beacon, it will wait 1min 15secs before looking for a beacon again. The range is from 0 to 255 (seconds.) The default setting is 48.

Note : *If there are no beacons available or working then you can use the Lap Timer in Track Day Mode. Disconnect your lap trigger module and select 0 for the Lap Blank period. This will then convert external Button **D** to be a manual trigger rather than the lap reset button. See Section 3.4.1 for further information.*

3.14.6 LED Startup Menu

```

LED Startup Menu
Ok   SPEED  UP

```

This sub-menu allows you to select which parameter indicated on the 3-digit red LED window is shown by default when the DigiDash2 is switched on.

The choice of displays is SPEED, RPM or GEAR.

3.14.7 Reset/Clear

```

Reset/Clear
Ok  CLEAR LOG  UP

```

This sub-menu enables you to either directly CLEAR the Logger memory, or RESET **all** MAX recorded values without having to either use the DigiTools software or visit each MAX hold screen to reset. CANCEL exits the menu.

3.1.4.8 MPH or KMH

MPH or KMH
Ok MPH Add

Configures the DigiDash2 for either Miles per hour, or Kilometres per hour.

3.1.4.9 Water Temperature Alarm

Water Temp Alarm
Ok 105 Add

This allows the user to program a warning alarm point for the Water Temperature in °C steps. Default = 105°C. To turn off the alarm (not recommended) set the value to 0. When activated the alarm is indicated by the letters **CTA** (Coolant Temperature Alarm) on the 3-digit red LED display.

3.1.4.10 Oil Temperature Alarm

Oil Temp Alarm
Ok 110 Add

This allows the user to program a warning alarm point for the Oil Temperature in °C steps. Default = **110°C**. To turn off the alarm (not recommended) set the value to 0. When activated the alarm is indicated by the letters **OTA** on the 3-digit red LED display.

3.1.4.11 Oil Pressure Alarm

Oil PSI Alarm
Ok 20 Add

This allows the user to program a warning alarm point for the oil pressure in 1 psi steps. Default = **20psi**. To turn off the alarm (not recommended) set the value to 0. When activated the alarm is indicated by the letters **OPA** on the 3-digit red LED display.

*NOTE – The ETB oil pressure sensor supplied with the DigiDash² has a mechanical low-pressure switch built-in should a separate dashboard warning light be required. This is calibrated to operate when oil pressure falls below 7.5 psi. If this switch is activated, the LED display will show **O.I.L.** on the 3-digit red LED display.*

3.1.4.12 RPM/Oil Alarm

RPM/PSI Alarm
Ok 2500 Add

This allows the user to set a minimum RPM value below which the oil pressure alarm (as set in the previous menu option) will NOT operate. This is especially useful should you wish to set the oil pressure to a value lower than normally experienced when a hot engine is idling and not have the alarm displayed unless the engine RPM is above a certain limit. To turn off the RPM/Oil feature, set the value to 0.

3.1.4.13 Aux Pressure Alarm

Aux PSI Alarm
Ok 20 Add

This allows the user to program a warning low pressure alarm point for the Auxiliary pressure in 1 psi steps. Default = **20psi**. To turn off the alarm set the value to 0. When activated the alarm is indicated by the letters **FPA** (Fuel Pressure Alarm) on the 3-digit red LED display.

3.1.4.14 Fuel Level Alarm

Fuel Level Alarm
Ok 20 Add

This allows an automatic warning of low fuel level, measured as a percentage (%) of a full tank. To disable the alarm, set to 0. When activated the alarm is indicated by the letters **FLA** on the 3-digit red LED display.

3.1.4.15 Shift Mode

Shift Mode
Ok 1 Add

The sequential shift lights can be programmed to come on in two different styles.

Style	LED Pattern displayed
0	Shift Lights OFF
1	Fully sequential
2	LED's change 3 blocks at a time

3.1.4.16 Shift RPM

Shift RPM
Ok 10200 Add

This allows the user to program the final shift light LED RPM trigger point. The shift RPM is set in 100 RPM steps.

3.1.4.17 Shift Delta

Shift Delta
Ok 500 Add

This allows the user to set the RPM change required to light the next shift LED. The shift delta RPM is set in 100 RPM steps.

Note that this RPM setting works for each LED or set of LED's and is dependent on the shift light mode chosen.

For Example: If the user sets Shift Light Mode = 1 (fully sequential), with a final Shift Light RPM of 10,000 RPM, each of the lower shift lights will illuminate at the RPM increment below this. If the shift delta set to, for example, 500 RPM, the shift lights would illuminate at:

First LED	Green	7500 RPM
Next LED	Green	8000 RPM
Next LED	Green	8500 RPM
Next LED	Yellow	9000 RPM
Next LED	Yellow	9500 RPM
Shift Light RPM Set Value	-	Final LED Red 10000 RPM

If the final Red shift light is illuminated for more than 1 second, the entire bank of shift lights will rapidly flash.

3.1.4.18 RPM Uplift %

RPM Uplift %
Ok 20 Add

This will increase the RPM value indicated by a percentage that can be defined by the user. This should **not** be used to calibrate the RPM reading – you should ensure that the pulses / cycle setting is correctly set.

3.1.4.19 Pulses per Cycle

Pulses/Cycle
Ok 4 Add

The DigiDash² will run with various different ignition systems. This menu option allows the user to tailor the system to their engine. The pulses/cycle setting effectively represents the number of cylinders the engine has. However the number of pulses generated can vary greatly depending upon the number of ignition coils on a particular engine or the output from an engine management system. The unit can be set from 1 to 8 pulses per cycle.

Note : Often the easiest way to set this parameter is to run the engine at an idle and read the RPM display. Most engines idle around 1000RPM when cold. If the reading says 500RPM then change the pulses-per-cycle to half of its current setting.

3.14.20 Speedo Calibration & Gear Calibration

Speedo Cal		
Ok	1748	Add

Gear Cal		
Ok	3266	Add

These are key numbers for the system and define the calibration of the speedometer, odometer and gear display. Note that for legal reasons the MPH displayed on the DigiDash reads 3% high at all speeds. If you have problems with the calculations we will be on hand to help. Before the DigiDash can be used the user must calculate and input the Pulses per mile and prop ratio figures. To do this a computer program is supplied on the floppy disk supplied. If you do not have access to a computer or need advice on the best place to measure the vehicle's speed please contact ETB Instruments for help.

Information you need to calibrate the unit:

- Wheel & tyre size
- Differential Gear ratio (when the speed sensor is fitted to propshaft)
- Details of the cars transmission system (RWD, FWD etc)

Note - You MUST use BOTH magnets supplied with the kit.

3.14.21 Track Length

Track Length		
Ok	3120	Add

Track Length specifies the length in metres of the race track. The track length can be set between 0 and 10,000 metres (10Km). This is used in the automatic calculation of split time points (up to 32 of them) round the lap. If you are unsure of the exact length of the track you should make this longer than you expect the lap to be.

3.14.22 Acceleration/Deceleration Test Start/Stop

Accel Test Start		
Ok	0	Add

Accel Test Stop		
Ok	60	Add

These two options allow the setup of the acceleration timer start and stop speeds.

Acceleration Timer: If the start speed is lower than the stop speed an acceleration run is timed.

Deceleration Timer: Conversely, a higher start speed than stop speed implies a deceleration (braking) run.

3.14.23 Vehicle Weight (Kg)

Veh Weight Kg		
Ok	600	Add

This allows the user to specify the weight of the vehicle in kilograms (Kg). This is used for the BHP / Power calculation. The valid range is 250 to 2500Kg. Default = 600Kg.

3.14.24 Primary (gear) Ratio


Primary Ratio		
Ok	1500	Add

This is the primary reduction gear ratio of the vehicles engine. For car engines this should be set to 1000 (1:1). For Bike engines the ratio is generally around 1.5:1 – which is entered as 1500 here. Check your service manual to get the correct ratio values for your particular engine.

3.14.25 Number of Gears

Num Gears		
Ok	6	Add

Allows the number of gears in the vehicle to be entered. The valid range is between 2 and 6.

3.1.4.26 Gear Ratios 1-6

This allows the entry of the vehicles gear ratios (please refer to your gearbox service manual for the correct ratios).

It is shown as a 4-digit number. The first digit represents the integer, whilst the others represent the three decimal places.

For example, for a ratio of 2.769 : 1 you enter 2769

3.1.4.27 Clock Date & Time Menu Screens

These screens allow you to set the date and time on the on-board real time clock. You can set the day, month, year, hour and minute using these screens.

3.2 Configuration Using DigiTools Software

The DigiDash2 is best configured using the DigiTools software supplied on the CD-ROM, as this allows access to all the settable features by the user.

Please refer to section 5 entitled “DigiTools PC software” for instructions on how to use the software for configuration and data analysis.

4 Using the DigiDash² Display

There are two main information areas on the DigiDash² Display. These can be cycled through various displays using the **A** or **B** buttons during normal use.



4.1 Button Functions (General Operation)

The DigiDash2 has two functions per button. A normal button press has one function and prolonged button press for more than 2 seconds has another. This allows you to switch menus, reset variables, select different modes such as configuration, all with just two buttons on the display.

Even more functionality is accessible when using the remote button kit (contact ETB for details) which is attached to the connector on the back of the display unit. This allows you to remote mount buttons on a steering wheel for instance. The remote button kit has 4 buttons. Two duplicate Button A and Button B, and two others, C and D, allow you to access extra functions.

Button A	Press Once	Moves to the next LCD display screen
	Hold Down	To Start / Stop the Logger. <i>(If enabled in DigiTools Configure)</i>
Button B	Press Once	<ol style="list-style-type: none"> 1. Move to the next RED display 2. When viewing the LST / BST screen on LCD display, if speed = 0 (i.e. you are in the pits) pressing Button B once will enable you to cycle through your recorded lap times on the LCD display
	Hold Down	Resets current LCD displays <i>(For example Max Hold Screens)</i>

**Holding Down Buttons A and B together enters Configuration Mode.
(Only possible if Speed = 0)**

Button C	Press Once	Moves to the previous LCD display screen
	Hold Down	No Function
Button D	Press Once	<ol style="list-style-type: none"> 1. Acts as a Start / Stop for the Lap Timer in Track Day Mode 2. Arms Lap Timer and acts a reset in Race Day Mode 3. GPS Option – Store Start/Finish & 3 split Lat / Long locations
	Hold Down	No Function

4.2 RED 3-Digit LED Display

The large three-digit (7 segment) display in the middle of the DigiDash² is used to display one of :-

1. Speed (MPH or KMH)
 2. RPM
 3. Engaged Gear
- plus
- Warning Alarms
 - Logger Status (*On or Off - Configured using DigiTools Software*)

Press Button **B** to cycle between Speed, RPM and Engaged Gear:-

4.2.1 Speed

The RED LED display can be used to indicate the speed of the vehicle. This can either be in miles per hour (MPH) or kilometres per hour (Km/h) depending on the unit of measurement selected. MPH or Km/h can be selected either directly via the display using Setup mode (see 2.1) or by using the DigiTools configuration software (See 4.1). The maximum possible indicated speed in MPH is 250, or if Km/h is the selected unit of measurement the maximum is 400.

4.2.2 RPM

Engine revolutions per minute (RPM) is displayed in increments of 100, with a maximum possible indication of 25.5, or 25,500 RPM. For example, the RPM shown below is 4,200 RPM.









4.2.3 Engaged Gear

The RED LED display can also indicate engaged gear. For this display to function correctly, the correct gear ratios of the gearbox must be entered either using the Display (Setup mode) or DigiTools software. The DigiDash² then calculates from the vehicle's Speed and RPM, the gear selected.

<u>Display</u>	<u>Description</u>
1	1 st Gear
2	2 nd Gear
3	3 rd Gear
4	4 th Gear
5	5 th Gear
6	6 th Gear
C	Clutch Down
N	Neutral (<i>for motorcycle gearboxes</i>)

4.2.4 Warning Alarms

One of the following warning alarms will be indicated on the RED LED display, in the event of monitored values falling outside the parameters specified in Setup.

	<u>Coolant Temp Alarm</u> When this is shown the Coolant Temperature has exceeded the specified limit.
	<u>Oil Temperature Alarm</u> When this is shown the Oil Temperature has exceeded the specified limit.
	<u>Oil Pressure / RPM Alarm</u> This alarm shows the oil pressure has dropped below the specified oil pressure limit, at an engine RPM higher than the set level. (e.g. Below 20psi when RPM is greater than 2000)
	<u>Fuel Level Alarm</u> You can set a percentage level of fuel remaining in the tank below which this alarm will be operated.
	<u>Fuel (AUX) Pressure Alarm</u> This alarm shows that <u>Auxiliary</u> Pressure has dropped below the set limit.
	<u>Oil Pressure Alarm (Mechanical Switch)</u> The oil pressure sensor incorporates a low-pressure switch (terminal WK) that when activated will show this display. The switch will operate below 7.5psi (0.5 BAR).

Note : The Alarm '**LEV**' indicates Oil Level warning. This warning can be configured using DigiTools if there is an oil level switch present on the engine you are running. (for example, some Yamaha R1 motorcycle engines have an oil level switch).

4.2.5 Logger Status

Using the DigiTools software for configuring the DigiDash², you can program this decimal point to



This decimal point signifies that the Logger is switched ON and recording data.

illuminate if the logger is switched ON to record data.

4.3 GREEN LCD Character Display

This is the main display for most sensor readouts. The LCD has several different “screens” of information available. Depending on which display options are enabled (see the DigiTools Configure section (4.12) of the manual for details) there are various screens that can be displayed. These are cycled between displays by pressing the **A** button. If Button **C** is connected, this button will cycle through the available screens in the opposite direction.

4.3.1 LCD Display Screens in Detail

	OILP : Oil Pressure in PSI (or BAR) <i>(Speed & Gear Can also be shown on this display via DigiTools Config)</i> OILT : Oil Temperature in °C (or °F) Water: Water Temperature in °C (or °F)
	Odo : Vehicle Odometer (Total) Bat : Battery Voltage Fuel : Fuel Level as a percentage of full
	RPM : Engine revolutions per minute MPH : Miles per hour (KMH = Kilometres per hour) Gear : Engaged Gear ('N' for neutral, 'C' for clutch-down)
	Engine : Elapsed Engine Run Time Aux Psi : Auxiliary Pressure in PSI <i>(+AFR & Turbo Boost if Selected)</i>
	Lst : Last lap number and time Bst : Best lap number and time
	L: Lap Number you are on T: Lap Elapsed Time S: Current split sector you are in (+ or – sector time from Best Lap)
	Accel : Start & Stop Speed (e.g. 0 – 60) (Decel = Deceleration timer) Time : Time Recorded
	Power : Instantaneous Estimate of Engine brake horse power (BHP) Max : Maximum recorded BHP Estimate
	G Turn : Lateral G-Force (+/- Indicates Left / Right Turn) G Accel: Longitudinal G-Force (+/- indicates Acceleration / Braking)
	TrTime : Elapsed Trip Time since last engine start (since last <u>Manual</u> Reset) TrDist : Trip Distance / Average Speed (Since last reset)
	Max OP : Maximum Oil Pressure recorded (since last reset) Max OT : Maximum Oil Temperature recorded
	Max WT : Maximum Water (Coolant) Temperature recorded Max DC : Maximum Battery Voltage recorded
	Max RPM : Maximum RPM recorded Max MPH : Maximum Speed recorded
	Max Turn : Maximum Lateral G-force recorded Max OT : Maximum Longitudinal G-force recorded

Brake F:R IRatio 0 : 0 1 0 %	Brake F:R : Front and Rear Brake Pressure (shown as % of maximum pressure sensor value) Ratio : % Ratio (Bias) between Front and Rear Pressures
UTC: 15h:39m:22s Date: 01/12/07	UTC : Universal Co-ordinated Time (if using GPS) or Time taken from on-board clock (24hour) Date : Current Date taken from GPS or on-board clock. DD/MM/YY Format
Lat: 51.823556 A Lon: 00.567383 A	Lat : GPS Latitude. "A" - <u>GPS Receiver Status</u> : A= Acquiring Satellites / Lon : GPS Longitude ! = Receiver Not Connected / ? = Receiver connected is not Compatible
Head MPH Alt m 195 SW 63 0034!	Heading : e.g. 0°=North MPH : GPS Speed Alt m: Altitude in metres ! / ? / A = GPS Status (as above)

4.4 Lap Timing

NOTE : In order to use the DigiDash² Manual Lap Timing it is necessary to have extra buttons connected to the Display, as Button **D** functions as your start/stop button. A remote 4 button kit for attaching to the connector on the back of the Display is available for purchase separately from ETB. References to Buttons **C** or **D** assume that you have installed this remote button kit.

The Lap Timer system can be operated in three different modes:

4.4.1 Manual Lap Timing / Track Day Mode

Track Day Mode involves triggering the timer manually each time the start / finish line is passed by pressing Button **D**.

To set the DigiDash² to Track Day Mode, the LAP BLANK period must be set to ZERO (0). The LAP BLANK period can be set to zero either directly using the Setup Menu on the display or via the DigiTools Configure Software.

4.4.2 Infra-Red Lap Trigger / Race Day Mode

By connecting the Lap Timer Receiver supplied to the **POWER/ TRIGGER** harness, infra-red trackside beacons can be used to automatically trigger the Lap Timer.

The Lap Trigger module must be mounted at the side of the vehicle such that it will be aligned to the trackside beacon when the car passes by. Note that some tracks have their beacons on the left-hand side of the track, whilst others have it on the right. If you intend to attend many different circuits it is convenient to ensure that the mount is easily changed from side to side.

To ensure the unit only responds to one beacon on a track it is important to set the LAP BLANK period correctly in the DigiDash² Setup:

As you approach your beacon to start the first flying lap then press button **D** (or Hold-Down Button **B**). This will reset the lap times and arm the lap timer ready for the beacon. The symbols >>> will appear in the lap timer window indicating the first flying lap.

For example: If you are lapping in around 1min 30secs set the Lap B lank Time to 75 (1min 15secs). This will ensure any spurious infra-red beacons detected in the first 75 seconds of a new lap are ignored.


If you wish to purchase your own Infra-red Beacon please contact ETB for details.

4.4.2.1 Testing the Lap Trigger Module

The **red STATUS** LED on the Datalogger can be used to verify that the Lap Trigger module is receiving a signal. In order to do this you must first set the operation of the **STATUS** LED on the Datalogger to Sensor Mode using the DigiTools Configure software (General Settings TAB). Any standard TV remote control handset can be used to test that the Lap Trigger is receiving a good signal. Simply point the remote-control at the installed lap timer module and the **red STATUS** LED should illuminate.

4.4.3 GPS Lap Timing

Please refer to the image below. In order to use the GPS receiver for lap timing, you must ensure that the DD2 is configured to use it for lap timing purposes, as an alternative to using an infra red system.



4.4.3.1 Using the GPS Lap Timing System

The GPS lap timing system is very simple to use and it will only take a few minutes for you to familiarise yourself with using the system for the first time.

Hardware Setup

Included in the standard package is the external button / GPS receiver harness for connecting the GPS receiver and wiring up 4 steering wheel mounted buttons. Two of these buttons replicate buttons **A & B** on the display, the other two allow access to additional functions and are specified as buttons **C & D**.

In order to use the GPS lap timing system, you must connect up button D, (which is the grey wire on the external button harness) to a single pole, single throw (push to make) switch, preferably mounted within easy reach on the steering wheel itself.

Once connected, this button is used to store the GPS positions of the start line and 3 intermediate splits. (Note that holding down this button for 2 seconds will arm the timer).

Setting the Start Line / Intermediate Split Time Co-ordinates

The system requires the user to drive round the circuit, pressing button **D** to store the GPS co-ordinates to memory:

As you cross the start / finish line, press button **D** and the following screen will be displayed.

The co-ordinates of this location will be stored in memory, and the next time this position is passed the system begins timing your first lap.



As you drive round the circuit you can divide the lap into 4 sectors. You simply press the button **D** to set the GPS location to trigger each split timer:



The DD2 will indicate your performance in relation to previously recorded split times as you lap the circuit. First the first lap, +9.99s will be shown as there are no previously recorded split times, but your second lap will indicate whether you are faster or slower than your previous (or best) lap.

Immediate recall of recorded laps on display

When the session has finished, you can select the LST / BST screen on the LCD to see your best (BST) lap time, and by pressing button **B** on the display, cycle through your recorded laps. These lap times will be stored indefinitely until you hold down button **B** for 2 seconds and reset the timers.

To begin a new session at a different location, simply repeat the above process to commit the new GPS locations to memory. You can also reset the locations using the DigiTools software.

4.5 Acceleration Timer

This allows the measurement of different acceleration and deceleration (braking) runs. By default the unit is configured to perform a 0-60mph run.

Using the timer is simple:

4.5.1 Acceleration runs:

Ensure the vehicle is starting below the start speed you have entered. For standing starts ensure the vehicle is stationary.

Use Button **A** button to choose the Acceleration-Timer Display. If you are overwriting a run hold down Button **B**. This will zero the stored value on the display.

The timer will start as soon as one of the magnets passes the speed sensor. The timer will automatically stop when the chosen stop speed is reached, and the time will be displayed.

4.5.2 Braking runs:

Perform the same procedure as above, making sure that your starting speed is higher than the chosen start speed. As you apply the brakes and the vehicles speed drops below the start speed the timer will be enabled. Once you have reached the desired stop speed the timer will stop and hold the deceleration time.

If you want to view the acceleration curve on a PC later, make sure you turn data logging on before you start the run. You can log multiple runs by turning the data logging on and off for each run.

Warning

The acceleration timer should be used with great care.
Do not use the timer on public roads.
Please ensure you give due consideration to the safety of other road users whilst using this feature.
Accidents resulting in the improper use of this feature invalidate the product guarantee.

4.6 Troubleshooting

Problem	Solution (try in order)
POWER LED on Datalogger is not lit	<ol style="list-style-type: none"> 1. Check the power and earth connections (Fused Red Wire and Single Black wire on POWER/TRIGGER Harness) 2. Check the Fuse
Nothing on the Display	<ol style="list-style-type: none"> 1. Check the CAN cable connectors are plugged in 2. Check that the Datalogger is powered (POWER LED is lit)
Speedo doesn't work	<ol style="list-style-type: none"> 1. Check magnets North-South orientation ('dot' must face away from sensor) 2. Check distance to sensor (1mm) 3. Check Loom Plug is tight 4. Test the Sensor using the Datalogger STATUS LED
Speedo is erratic or poor at high speeds	<ol style="list-style-type: none"> 1. Distance between magnets and sensor is too great 2. Magnets are mounted on a vehicle part that has lateral movement. 3. Sensor Bracket is moving in relation to the magnets / Bracket too weak.
Gear Display does not show engaged Gear	<ol style="list-style-type: none"> 1. Check that you have entered the Gear ratios of your gearbox using Setup Mode 2. Check that you have correct Speed and RPM input signals 3. Ensure that you have entered the correct values for the SPEED CAL and GEAR CAL using the DigiTools Calculator
I get interference when the engine is running	<ol style="list-style-type: none"> 1. Check the connections are tight 2. Use the CDI or ECU tacho output if possible
Display sensors show 'NC'	<ol style="list-style-type: none"> 1. Check wiring to sensor and connections 2. Check that there is a good ground connection for the sensor (this is made via the sensors body)
The lights are too bright	<ol style="list-style-type: none"> 1. The brightness of the displays is variable. Use the SETUP-MODE to change the brightness

5 DigiTools PC Software

Supplied free with the DigiDash² is a comprehensive software package. This software is designed to run on any Microsoft Windows 32bit operating system (Win 98, ME, NT, 2000, XP and Vista). Minimum specification for the PC is a P133 with 32MB of memory, and an 800x600 SVGA display.

(Please note that this manual does not contain information about using Windows, and assumes that you are already familiar with standard Windows operations such as click, double-click, right-click, drag and drop etc. For further information on using Windows please refer to the instructions supplied with your operating software)

5.1 Connecting the Serial Cable to a PC

To configure the DigiDash², first connect the Serial cable to the port on the Datalogger labelled “**SERIAL**”. This allows the user to connect to a PC computer via the built-in RS232 serial port.


If there is no RS232 port available, a USB/Serial Adapter is included as standard – note that you must install the USB/Serial adapter drivers for Windows prior to using the adapter. A separate setup CDROM is included for this adapter.

5.2 Installing the DigiTools Software

- Insert the DigiTools CD into your CD-ROM Drive.
- Using the mouse, Left double-click on “My Computer” Icon
- Right-Click on CD-ROM Drive Icon and select “Explore”
- Select all files shown on CD-ROM and by Right-Clicking on these files, drag and drop them into a suitable folder on your Hard Drive.

To start the DigiTools program, double-click using the left mouse button on the ETB icon.


Once the program is running you should see the following Menu with three main sub-programs:-



To select the program you require, left-click on the appropriate button. To exit the DigiTools click on the EXIT button.

5.3 DigiDash² Configure

For full access to all the DigiDash2 parameters and functions that can be specified by the user, you must use the DigiTools Configure program. After clicking the DigiDash2 Configure button, the box below will be displayed.



5.3.1 Version Tab

5.3.1.1 Serial Port

To automatically connect the Datalogger to a PC, you must first select the COM Port that your PC is using to connect to the DigiDash2. If you are using the RS232 serial port, this is usually set as COM Port 1. Other COM Ports can be specified if necessary (usually when using a USB port).

5.3.1.2 Logger Version

When the Datalogger is connected to the PC, the DigiDash2 Version and Revision number will be displayed in these boxes.

5.3.1.3 Connected Modules and Status

Information on any modules connected to the Datalogger via the **DIGICAN** connection (such as the Display) will be indicated here, including their version number and serial number.

5.3.1.4 Logger Memory

The maximum available memory installed in the Datalogger will be displayed here when the unit is connected to a PC. The Pro+ memory size available for recording data is 69.2Mb.

5.3.1.5 DigiDash Read/Write

After selecting the correct COM Port (5.3.1.1), you can test the connection using the DigiDash “**Read Config**” buttons. The **Read Config** button is used for downloading or “reading” the current configuration of the DigiDash2 to the DigiTools.

If the Display module is connected, by clicking on the **Read Config** button you should see the following shown on the Display:



The DigiTools Configuration menus will now be set to the current settings of the DigiDash2. A box will appear confirming that the Configuration has been correctly downloaded.


Once you have accessed the menu screens in the Configuration program and changed the parameters to your desired settings, the “**Write Config**” button is used to upload or “write” your configuration to the DigiDash2. A dialog box will appear confirming that your configuration has been correctly uploaded or “written” to the DigiDash2.

5.3.1.6 File Save/Load

You can save files with a particular configuration to your hard drive by clicking on the “**Save Config**” button. These files will be saved as a “.dcf” file type. This will enable you to save different DigiDash2 configurations and upload them as desired.

To load a previously saved file, simply click on the “Load Config” button, locate the desired configuration file and click “Okay” to load the configuration to the DigiTools software. Remember that once the file is loaded, if you wish to program the DigiDash2 to the settings contained in the file, you must then click on “Write Config” in order to upload the settings to the Digidash2.

5.3.2 General Tab



5.3.2.1 Odometer

The Odometer reading indicates the total recorded mileage. Any changes to the vehicle's mileage can only be done at the factory.

5.3.2.2 Accel / Brake Timer

Here you can enter the start and stop speeds for timer acceleration runs or for brake tests. Enter a low start speed to higher stop speed for acceleration timing or a high start speed to lower stop speed for braking tests.

5.3.2.3 G Force Sensor

This box allows you to swap the lateral and longitudinal axes of the G-Sensor on board the Logger, should the positioning and orientation of the Logger require it. You can also swap the +/- signs for each axis.

5.3.2.4 Max/Hold Timer Reset

Checking the box will automatically reset to zero all the maximum recorded values when the Digidash is switched on. Two additional radio buttons enable you to modify the reset function of button B on the display. Pressing and holding button B for 2 seconds will either reset all Max Holds and Timers or only reset the screen shown on the LCD display, depending on which option is selected.

5.3.2.5 Display Units

Allows the user to select the units of measurement displayed on the DigiDash – either metric or imperial units can be chosen for speed, pressure and temperature readings.

5.3.2.6 Time / Date Display

The date and time (written to the log filename and displayed on the dash) can be derived from either the (manually set) on-board Real-Time Clock or from the GPS. GPS date and time is fixed to UTC timezone.

5.3.2.7 Speed Display

The speed indicated on the display can be switched between that measured by the hall-effect speed sensor and magnets supplied or GPS derived speed (requires GPS option). When using the hall-effect sensor, the indicated speed is +3% for road use. GPS derived speed has no such uplift and care should be taken if using GPS speed on the road as this is the actual speed of the vehicle.

5.3.2.8 Module Data

The PRO+ includes 4 0-5v analog channels, which can be displayed as Turbo Boost, Brake Bias (Front and rear) and Air/Fuel Ratio. Alternatively a separate expansion module is available offering 8 analog channels plus 2 extra wheel speed channels. By checking this box, the 4 PRO+ channels take precedence over the expansion module when displaying Boost, Brake Bias and AFR.

5.3.2.9 Logger Box LED


The red status LED on the Datalogger can be set to either:

Sensor Status – used to check that the lap trigger, speed sensor and RPM inputs are receiving a signal

Logger Status – when the LED is lit the logger is switched on and recording data

GPS NOT Locked – for PRO+ units with GPS enabled, the light will indicate that the GPS receiver has not locked onto satellites.

5.3.3 Alarms Tab



5.3.3.1 Engine Alarms / Battery Alarm / Fuel Level / Auxiliary-Fuel Pressure Alarm

Enter set values at which the alarms will activate. Temperature alarms activate above these values, whereas fuel level and pressure alarms activate below when monitored values drop below these limits. The Battery Alarm can be adjusted in increments of 0.2 volts and can be set to activate when the supplied voltage drops below a certain preset value.

The Oil pressure alarm can also be set to only activate should the RPM reading exceed a preset value. Should you not wish the oil pressure alarm to be related to RPM, simply set the RPM value to zero.

5.3.3.2 Oil Alarm Display / Oil Alarm Switch

When using the built-in low Oil pressure switch on the ETB sensor, the default setting is for the display to show O.I.L.. The ETB sensor has a normally open contact (NO) that closes when pressure is below 7.5 psi.

However, you may wish to use another switch such as the original engine pressure switch, for which you can specify whether the switch contacts are normally open (NO) or closed (NC).

For engines equipped with an Oil level switch (e.g. Yamaha R1 engines), you can change the switch setting to NC, and the indicated alarm to '**LEV**', which indicates "LEVEL".

5.3.3.3 Speed Alarm

The DigiDash² incorporates a Speed Alarm.

Using this menu box, you can specify the speed at which the AUX warning light on the display will illuminate. (Please see Section 4.3.4 for setting the AUX warning light to Speed Alarm Mode).


a) Under – Enables you to set the pit lane speed limit, so that as you drive down the pit lane, you must ensure that this light remains ON in order to avoid pit lane speeding. (It is advisable to set the a value just below the pit lane speed limit !)

b) Over - You can set the AUX light to illuminate if the vehicle's speed exceeds the set limit.

5.3.3.4 Alarm Hold Over Time

This is the period in increments of 0.2 seconds that defines the length of time the display will show a warning alarm after the condition that originally triggered the alarm has returned to normal limits. A warning alarm will show indefinitely if continuously triggered.

5.3.4 Display Tab



5.3.4.1 LCD/LED Display Options

The main area of the display tab is used to turn on or off display screens on the green LCD of the display unit. Four tabs relate to the model of DigiDash you are using. The PRO+ tab is selected on the image above showing all screens are selected. In order to display a particular screen, ensure that the corresponding check box is ticked.

5.3.4.2 Display Settings

You can alter the brightness and contrast settings by changing the value of these boxes. LED brightness (all LED warning lights and RED 3-digit display) ranges from 0 to 15, 15 being maximum brightness. Similarly you can alter the contrast of the green LCD display, 10 is lightest, 0 is darkest.

Display Lap Update

When the end of a lap is triggered (either manually, by the infra-red receiver or GPS) the LCD display switches automatically to the LST/BST screen showing your last and best lap times. Use this setting to control the period in seconds this display is retained before switching back to the original screen selected.

5.3.4.3 DP on LED Display




You can use the decimal point of the red LED display to show when the logger is switched on and recorded data.

5.3.4.4 AUX Light LED Mode

The function of AUX warning light can be selected using these radio buttons. Choose between:

- Logger On – Logger switched on and recording data
- Neutral Gear – For Bike engined cars
- Speed Alarm – Over or Under speed warning as selected using the Alarms Tab (5.3.3)
- Camera Alarm – illuminate when in proximity of a speed camera (DD2- LITE only)
- GPS NOT Locked – warn if the GPS satellite signal is lost.

5.3.5 Shift Lights Tab



5.3.5.1 Shift Light Setup

Shift Lights Mode – Switch the mode of the rpm shift lights between:

Off – Switch off shift lights

Norm – Fully sequential operation – each LED will illuminate in sequence at intervals of the preset RPM delta value (see below)

Block – Switches in blocks – 3 Green LEDs to 2 yellow LED's to Main Red Shift light.

5.3.5.2 Flash on Max shift time


If the main RED shift light is on for more than 1 second the bank of shift lights will repeatedly flash. Turn this feature off by un-checking this box.

5.3.5.3 Shift Points

Peak – This is the value at which the main RED shift light LED is illuminated (max. RPM)

Delta – This the RPM value each LED will progressively illuminate. (E.g. Set the value to 500 if you wish each shift light LED to come on in 500 RPM intervals.)

5.3.6 Lap Tab



5.3.6.1 Lap / Hill / GPS Times

Best Lap Reset - The LST / BST display on the green LCD can be selected to automatically reset on power up of the DigiDash system as well as by pressing and holding down button B for 2 seconds. Alternatively, you can reset this value only when the LST/BST screen is displayed and button B is pressed and held for 2 seconds.

5.3.6.2 Lap Timing Mode

Select between either the infra-red lap timing system or if enabled, by using the GPS receiver.

GPS Lap Coords (GPS Lap Timing only)

Please refer to section 4.4.3 for more information on how to use the GPS lap timing system. By pressing button D as you drive round the circuit, the Latitude and Longitude of the GPS start / finish line and 3 split time locations is stored here. By saving this configuration file and these particular GPS co-ordinates, when you return to the same track for a second time, you can upload the

configuration file with these co-ordinates and the GPS lap timing will use the same GPS co-ordinates as your previous visit to the track.

5.3.6.3 Sprint / Hill Mode (Infra Red Lap Timing)

By checking this box, you can instruct the DigiDash timer to start automatically on leaving the start line (immediately on detection of first speed sensor magnet). You must reset and arm the timer by pressing and holding button D for 2 seconds.

5.3.6.4 Beacon / Button Options (Infra Red Lap Timing)

This is the period in seconds that the Digidash will ignore any other infra red signals received by the lap timer receiver as you go round the circuit (in case of other infra red beacons positioned around the track). To ensure the unit only responds to one beacon on a track it is important to set the LAP BLANK period correctly in the DigiDash² Setup:

As you approach your beacon to start the first flying lap then press button **D (or Hold-Down Button **B**). This will reset the lap times and arm the lap timer ready for the beacon. The symbols >>> will appear in the lap timer window indicating the first flying lap.**

For example: If you are lapping in around 1min 30secs set the Lap Blank Time to 75 (1min 15secs). This will ensure any spurious infra-red beacons detected in the first 75 seconds of a new lap are ignored.

You can also select between computed distance or entered distance for split times when using infra red lap timing. Computed distance will automatically divide the lap up into the chosen number of splits (up to 32), or if the track length is known, into 3 preset distances from the start / finish line.

5.3.7 Gear Tab

The Gear indicator setup page is used for entering the forward ratios of your gearbox.


Input the number of forward gears in the vehicle's gearbox.

Enter the primary ratio. This ratio is generally for motorcycle gearboxes that do not have a 1:1 primary ratio. For a standard roadcar this should remain as 1.000.


Input the gear ratio of each forward gear. These are very important as the ratios are required in order for the DD2 to calculate which gear you are in.

5.3.8 Fuel Tab

Use this screen for selecting the type of fuel sender that will be used in conjunction with the DigiDash². The ETB float arm sensor is supplied as standard and therefore the default setting is to use this fuel sensor. Alternatively you can set the DigiDash² to work with either VDO lever-arm float units, VDO Dip-Pipe fuel senders, or a Capacitive Type Fuel sender. All these fuel senders are available for purchase from ETB Instruments.



5.3.9 Calibrate Tab



Use this box for entering the pulses for the Tachometer (RPM) input.

Effectively, the number (1-8) represents the number of cylinders that the engine has.

However, wasted spark systems or ECU outputs may vary the number of pulses per engine cycle, and therefore this number can be changed to accommodate.

The weight of your vehicle can be entered using this box. This is used by the PRO+ in estimating the brake horse power (BHP) of your vehicle.

The values entered in the Speed Calibration box are essential not only for the speed reading to be accurate, but also for the engaged gear display to indicate correctly.

Clicking on the Goto Calculator button will automatically open the DigiTools Calculator program to obtain the correct numerical factors, depending on where the speed sensor is located and your vehicle's tyre size.

5.3.9.1 DigiDash² Calculator

The DigiDash2 Calculator is used for calculating the required Speedo and Gear Calibration Ratios that are essential for the DigiDash 2 to show speed and gear correctly.

You will need information concerning your vehicle, including:

Speed Sensor Location

Tyre Size

Differential Ratio (Final drive)

First, select the Drive and Sensor position and the Type of Tyres (road tyres are specified by nominal width, tyre profile % and wheel diameter, e.g. 185-60-13, marked on the sidewall. Slick tyres are specified by nominal diameter. In each of these cases the calculator window will allow you to enter the relevant measurements and will calculate the rolling circumference (the distance covered by the car in one revolution of the tyre) from them. Though there may be some difference between the calculated value and the actual rolling circumference (for instance as the tread wears), the difference is typically very small and does not affect the configuration in use.

However, if you experience problems with the accuracy of the calculated figures or the required measurements are not available, select “unknown tyres” and enter the rolling circumference directly.

Select the final drive type (sprocket and chain or differential) and enter the required data in the Final Drive Ratio pane. Note that if you change drive ratios between circuits this must be reflected in the configuration to ensure correct speed and gear display and logging.

Once you entered the details of your vehicle, click the “Calculate” button and the yellow boxes will show the resulting values. Click “Goto Configure” to directly input the values on the Configure screen.

Calculator

Drive and Sensor Position

- ☐ Front Wheel Drive, Front Wheel Sensor
- ☐ Front Wheel Drive, Rear Wheel Sensor
- ☒ Rear Wheel Drive, Front Wheel Sensor
- ☐ Rear Wheel Drive, Propshaft Sensor
- ☐ Rear Wheel Drive, Rear Wheel Sensor

Type of Tyres

- ☒ Road Tyres
- ☐ Slick Tyres
- ☐ Unknown Tyres

Final Drive Type

- ☐ Sprocket
- ☒ Gear Diff

Road Tyre Details

Front Tyre Width: 275 mm Rear Tyre Width: 275 mm
 Front Tyre Profile: 80 % Rear Tyre Profile: 80 %
 Front Wheel Diameter: 19 inches Rear Wheel Diameter: 19 inches

Final Drive Ratio

☐ Gear Driven Diff
 Differential Ratio: 3.21 :1

Tyre Information

	RR	Circumference
Front Tyre	461 mm	2898 mm
Rear Tyre	461 mm	2898 mm

Results

Speedo Cal: 1110
 Gear Cal: 3210

Menu Control

[Help](#) [Back to ToolBox](#)

5.3.10 Logger Tab


Logger Configuration

This box is used for controlling how the Logger is switched On or Off to record data.

There are 2 Modes of operation:

Display Button A can be set to turn the Logger On or Off. When you wish to start recording data, hold down Button A for more than 2 seconds and the LCD display will indicate that the Logger is switched On. Similarly, hold down Button A to switch the Logger Off.

Logger Switch. The Orange / Brown wire on the green **POWER/TRIGGER** connector can be used for switching the Logger On or Off. This wire should be connected to a Single Pole Single Throw Toggle switch (not supplied) for switching to Ground.



You can pause the recording of data (to save memory) by setting the Logger to pause when:

The vehicle is stationary
(i.e. Speed = 0)

Or
The engine is switched off
(RPM = 0)

The DigiDash Lite has the facility to log one data trace from Oil Pressure, Speed, RPM or Distance, selected with this drop down box.

The Logger sampling rate can be switched between 10Hz & 20Hz. This means that the Logger will record data values either 10 or 20 times per second. A sampling of 10Hz is usually sufficient for most applications.

Note that by increasing the sample rate to 20Hz, you will reduce the amount of time that the Logger can record data, as a rate of 20Hz increases the amount of memory used for each second of data recorded.

5.4 DigiDash² Analysis

(For more information on using the DigiTools software please see the separate DigiTools user manual).

The standard internal memory capacity of the DigiDash² PRO+ is 69.2Mb . Each time the Logger is started the DigiDash² records data for each parameter (as listed below) until it is manually switched off (or when ignition is switched off if configured using DigiTools to do so). The DigiDash² automatically treats this as a single session or data set. You can record up to 16 sessions or data sets, providing that the memory capacity is not exceeded recording previous sessions.

For information on how to start / stop the logger, please refer to Section 4.1, which explain how to configure the Logger and the associated button functions.

The standard vehicle parameters (channels) that are logged are:

- Engine Revs (RPM);
- Speed (MPH or KMH);
- Engaged Gear;
- Brake %
- Oil Pressure;
- Oil Temperature;
- Water Temperature;
- Fuel Level;
- Auxiliary Pressure (Can be used for Fuel or Boost Pressure);
- Battery Voltage;
- Lap Number
- Lap Times (s)
- Split Times (s)
- Longitudinal G-Force;
- Lateral G-Force

Additional 0-5v analog channels on the DigiDash² Pro+ enable you to connect any type of sensor that outputs a signal ranging from 0 to 5 volts.

5.4.1 Downloading Logged Data from the DigiDash²

When you wish to analyse the logged data, you must connect the serial cable to the Datalogger and your PC and click on DigiDash2 Analysis in DigiTools. The following screen will appear:

Data Set A & B Options:
These buttons allow you to load previously logged data sets from your hard drive. Once a data set has been downloaded from the DigiDash² you can click on Save Data Set (A or B) to store the file on your hard drive.

You can also save data sets in Microsoft Excel (.csv) format.

When downloading logged sessions from the DigiDash, you can save it to either A or B Data Sets, which allows you to overlay to different sets of recorded data.

To download a data set from the DigiDash², you must first select the COM port being used by your computer.

By clicking on the Download menu, a new menu screen will appear. You will see a list of logged sessions, including each file size and total memory usage. This menu is shown on the next page (Section 5.4.2)

To download a particular session, select the corresponding data set number (1-16) and select if you want it to be downloaded as a type A or B data set. Then click the "Download" button. A bar will appear showing the progress of the download process.

Once downloaded, you can click on the "View Data" button to start analysing the recorded data.

You can edit and store general information about your vehicle's set-up for each data set. For example, you can note your tyre pressures during a particular logging session and upon saving these notes, they will be added the data set file.

5.4.2 Download Menu Screen

Latest Session Information

Newest Log Files		Log Length		GPS/RTC Date and Time	
	Time	Size		day/month	24Hr
Log Session 1	3.12 mins	74.30 kBytes		25/02	07h:53m
Log Session 2	3.08 mins	73.36 kBytes		25/02	07h:47m
Log Session 3	NA mins	NA kBytes		NA	NA
Log Session 4	NA mins	NA kBytes		NA	NA
Log Session 5	NA mins	NA kBytes		NA	NA
Log Session 6	NA mins	NA kBytes		NA	NA
Log Session 7	NA mins	NA kBytes		NA	NA
Log Session 8	NA mins	NA kBytes		NA	NA

Oldest Log Files

Prev Logs
Next Logs
Refresh

Memory Usage

Total	69.21 Mbits
Used	1.18 Mbits
Free	98.29 %

Clear All Log Sessions

Download Data

Download Log Session **1** to Memory **A**

☒ Automatically Save Data to File
☒ Use Log Date and Time in Filename

Download

View Data **Back to Log Analysis**

5.4.2.1 Latest Session Information

The last recorded file will be shown as log session 1. Previously recorded files will be then bumped down the list until Log session 16, after which the file will be discarded. The log file displays the time and date of when the file was recorded on the right hand side of the download data menu for reference.

5.4.2.2 Memory Usage

These boxes show the amount of memory used in Mbits and the % of memory still available. If you wish to discard all previously recorded data, click on the Clear All Log Sessions button.

5.4.2.3 Download Data

You can select a particular log session from the list by selecting the appropriate number in the Download Log Session drop down box. You can also specify whether you wish to record the file as an A or B memory file.

The check boxes allow automatic saving of a file when selected for analysis and the time and date can be saved as part of the filename used.

5.4.2.4 View Data

After selecting a particular log session, you can then click on View Data to open the Data Analysis window.

5.4.3 Data Analysis

View Data Tab Menus:


File - Load different Data sets or print the plot area to your printer or a file

Data - Select the X and Y axis data variables for plotting on the graph, and select which data is plotted and in what colours.

View - Zoom and pan the data plotted on the graph. You can also assign a smoothing factor to the data plotted which averages the inputs and simplifies the data plot. If you wish to plot all data and the lap overlay data, click on the Lap overlay button in the Plot box.

Marker - Assign labels or markers to the data plot, show statistics on the data.

Option - Change the units of measurement of the plot data, swap the G sensor axes, or modify the gridlines of the plot area.



Plot Pane Tabs

You can change the line characteristics of each data set as plotted on the graph, to help differentiate them, by selecting one of th

5.4.3.1 Plot PaneTabs:

Plot Data - Shows the graph of selected data traces for the whole session or selected laps after selecting the Lap Times tab and choosing the lap data you wish to overlay.

Lap Times - This tab shows your total and split times of each recorded lap. You can overlay 2 sets of lap data by selecting the lap number and data set in the 'Select Laps to Overlay' boxes. To create a file compatible with Bosch LapSim analysis software, click on the Export button after selecting the desired lap.

Data Notes (A & B) - These are your notes relating to your vehicle's Setup at the time the data was recorded. These notes are edited using the "Edit Data x Notes" button from the Log Analysis window.


Track Map - Plots a map of the circuit based on G force and measured speed data or using the optional GPS module data (Pro+ only).

G Circle - Plots longitudinal and lateral G Force against each other. This enables you to see how well you are using the car's "traction circle" - how efficiently you are using the tyres round the lap.

Video Overlay - enables you to synchronise in car video with the corresponding session data to produce a video file output with DigiDash data overlayed on it in real time.

Engine Analysis - shows engine power and torque graphs, estimated from the acceleration, speed and configured weight of the car.

Appendix 1– Wiring Schematic




Connecting to an Existing Wiring Loom / Switches

The **SENSOR** cable (blue plug) has a number of input wires that should be connected to your existing wiring loom. The DigiDash2 requires that on some of these inputs, in order to operate a warning light for example, the input receives 12 volts. This is explained in more detail below:

SENSOR Cable Inputs that require switched +12v

There are 4 input wires on the **SENSOR** cable that require 12v applied to the input in order to operate:

- **Brake Pedal Monitor** (RED wire)– This input is used for recording use of your vehicle's brakes. When using the Logger, the length and time you depress your brake pedal will be recorded for later analysis using DigiTools. This input requires that upon operation of the brake pedal, +12 volts is supplied to the DigiDash. If the brake lights are switched to 12v in order to illuminate, a possible connection point would be to the positive switched supply to the Stop / Brake lights.
- **Main Beam** – (GREY wire) When 12 volts is applied to this input wire the blue main beam warning light will illuminate.
- **Rear Fog** – (PURPLE wire) When your rear fog lights are switched on, the warning light should illuminate.
- **Left / Right Indicators** (GREEN wire with 2 individual feeds (red and grey) – The turn indicators are wired separately. There are diodes in the cable in order to prevent a short circuit.




Simplified Wiring Example for +12v Switched Warning Light

SENSOR Cable Inputs that require switch to Ground (-ve)

There are 2 inputs on the Sensor cable that require a switch to ground in order to operate:

- **Brake Fail / Handbrake Warning Light** – (DARK BROWN wire) – For the brake fail warning light on the display to illuminate, the input feed must be switched to ground (negative earth). This can be wired directly to the brake fluid level switch on the brake fluid reservoir, or if the handbrake is connected to the same circuit, the handbrake switch.
- **Neutral Warning Light** – (LIGHT BROWN wire) – This is intended for motorcycle gearboxes that have an output for a dashboard Neutral indicator light. This switches to ground during operation.



Appendix 2 - Speed Sensor Installation

There are 2 small, powerful magnets supplied with kit. These magnets are mounted on a surface that rotates in relation to vehicle speed and supply electrical pulses as they pass in front of the speed sensor to the DigiDash².

The **POWER/TRIGGER** harness with the Green 15-pin connector incorporates the speed sensor. The sensor can be disconnected from this harness to aid ease of installation.


You must first locate a suitable position for mounting the speed sensor and magnets on your vehicle. The speed sensor and magnets are commonly mounted in one of three locations: -

Prop-shaft (either at the differential end or gearbox end) (See Section 4.7.1)
 Drive-shaft Coupling (with Sensor mounted on gearbox or differential)
 Front Hub (with sensor mounted on steering arm)

The recommended gap between the sensor and top surface of the magnets is **1mm** and therefore you must ensure that whatever location is used, any movement in the position of the magnets is replicated in the movement of the sensor to maintain a constant gap. You will need to fabricate a strong bracket to hold the sensor in place, and bolt this bracket to a suitable mounting point.


Here are 2 examples:-

Prop-Shaft Mounting



Magnets glued in position. Liberal application of a strong adhesive such as Araldite will ensure that the magnets do not become dislodged during use.

Front-Hub Mounting




Strong mounting brackets that hold the speed sensors in position. The brackets have been mounted in positions that move in unison with the magnets.


Important! – The speed sensor is polarity dependent. This means that the magnets must be mounted dimple-side DOWN, facing away from the sensor.

Important! - The recommended gap between the speed sensor head and top surface of the magnets is 1mm.

Speed Sensor Alignment



Appendix 3 – Display Mounting Template (to scale)



Appendix 4 – ETB Fuel Sender Fitting Instructions

! Safety Instructions

Caution: No Smoking! No open fire or source of flame!

Fitting the sender to the fuel tank

If an installation must be made, the fuel tank must be completely drained first. Drain the fuel into an approved container. REMOVE THE TANK WHENEVER POSSIBLE.

Warning : Risk of explosion exists due to the presence of residual gases in the tank!! Make sure that the tank is aired sufficiently (at least 15 minutes)

- Choose the sensor location carefully, making sure that the float arm of the fuel sender will not conflict with any baffles, pipes or internal obstructions inside the fuel tank. Also ensure that the float unit does not come into conflict with the side walls of the tank.
- Make a preliminary hole in the installation opening using a drill and then finish the hole using a compass saw or piercing saw. Comply with the safety instructions of the tool manufacturer.
- The rubber gasket can be used as a template for marking the bolt holes. The main hole in the tank should be cut to 40mm Diameter. Six Bolt holes (diameter 5mm to 5.5mm) should be drilled around the centre of the main hole on a P.C.D. (pitch circle diameter) of 60.4mm. Pay special attention to the orientation of the float arm in relation to the bolt holes.
- Clean the tank of residue from the drilling or sawing work.
- Fix the fuel sender to the tank using M5 Bolts, washers and nuts.

Fuel Sender Adjustment

Should adjustment to the length or angle of the fuel sender be necessary, please bear in mind the following points:-

- To adjust length, **do not** remove the arm from the brass pivot point.
- Shortening can be done in two ways: either add a series of zigzag bends in the arm to shorten the length; or by cutting the arm in half and rejoining to the correct length. We have found that as long as a suitable thread-locking agent is used, (one that is insoluble in petrol e.g. Loctite 290), simple 2-way screw terminal blocks can be used:-

Terminal Blocks Standard Screw Terminal Polyethylene



(5 amp is generally the best size)

- To lengthen, it is suggested that a suitable gauge of brass rod be added in a similar method to above.

Important ! – Removing the float and re-bending the arm around the float is not as easy as it sounds, and therefore we recommend that the bend around the float is maintained, removing a centre section of the arm instead.

Important ! – Ensure that the fuel sender float does not reach the top or bottom the tank before the float arm has reached its full span of travel. (For example, if the fuel sender float hits the top of the tank before reaching its end stop, the fuel gauge will never read full.)

Important ! – It is advisable to allow a gap between the bottom of the tank and the lowest point of travel of the Fuel sender float unit in order to provide a reserve quantity of fuel after the gauge reads empty.

Appendix 5 – Lap Trigger Alignment

Lap Trigger Alignment

Directions:

The lap trigger uses an infra-red detector to sense when the lap has been completed by starting and stopping a timer when it sees an infra-red source. The infra -red source (beacon) is commonly found at most circuits and is not supplied with the DigiDash. The DigiDash will trigger off any infra-red source. This includes other beacons at track or test days and the circuits own split-time beacon(s) if it has one.

In order to stop the lap trigger giving multiple readings due to multiple beacons a **lap timer enable time** can be programmed into the DigiDash. This stops the DigiDash, once triggered, looking for any other beacons until the preset time has elapsed.


For example

The Digidash will trigger off the first beacon on the pit wall, whether it is your beacon, another competitor's or the circuit beacon. Set the lap enable time to a value less than your fastest lap so that the unit cannot trigger until you are just about to complete a lap. This stops any false triggers on split time beacons.

If people are using split time beacons then as you are about to start your first timed lap, press button 4. This will reset your lap timer to be ready for a new timed session. You only have to do this if people are using split beacons because on your first lap out your DigiDash may trigger on a split beacon and your lap enable time will prevent the DigiDash triggering at the start and finish line.

Potential Problems:

The Sun is the biggest infra-red source around and may cause the unit to false trigger if pointed directly at it. Try to keep your lap trigger pointing horizontal and if possible tilted down slightly. The problem only really occurs when the Sun is low in the sky and shining directly across the start and finish line where your beacon is situated. The lap enable time preset value will stop the Sun triggering the unit at other points on the circuit.



Appendix 6 – Specification

Power Supply

7V - 14V DC Negative Earth only
Maximum current consumption 400mA
Fuse value: 1.5A

Environmental

Ingress Protection Level - Display IP54
Operational temperature range 0 °C to 40 °C
Storage temperature range -10 °C to 60 °C
Avoid contact with Oil, Petrol and other solvents.

Physical

Display Dimensions	: 160.4mm x 90mm x 28mm (Exc. Connectors)
Weight	: 400g

Cleaning/Care

Use a damp cloth to clean the unit. Do not use abrasive cleaners or chemicals.
The unit is splash proof to water, however it is not designed for submersion.

Warranty

ETB Limited Warranty

ETB Instruments Limited warrants all merchandise against defects in factory workmanship and materials for a period of 12 months from date of purchase. This warranty applies to the first retail purchaser and covers only those products exposed to normal use or service. Provisions of the warranty shall not apply to an ETB product used for a purpose for which it is not designed, or which has been altered in any way that would be detrimental to the performance or life of the product, or misapplication, misuse, negligence or accident. On any part or product found to be defective after examination by ETB Instruments Limited, ETB Instruments Limited will only repair or replace the merchandise through the original selling dealer or on a direct basis. ETB Instruments Limited assumes no responsibility for diagnosis, removal and/or installation labour, loss of vehicle use, loss of time, inconvenience or any other consequential expenses. In the event of merchandise being returned to ETB Instruments Limited, The responsibility for payment of delivery rests with the customer. The warranties herein are in lieu of any other expressed or implied warranties, including any implied warranty of merchantability or fitness, and any other obligation on the part of ETB Instruments Limited, or selling dealer. Your statutory rights as a consumer are not affected.